

Pneudraulics, Inc.

FAA Certificated Repair

Station No.: PD6R469J

Capabilities List - ALL LISTINGS ARE ACCESSORY, CLASS I

Authorized for use on Repair
Station Operations Specifications
 Ref: QSP 21.101 for use and modification
 *EASA release only part numbers

Manufacturer	PDI (Mfr) P/N	Nomenclature	Manual Type
Pneudraulics	1000-4	Hydraulic Relief Valve	OM
Pneudraulics	1033-5	Hydraulic Relief Valve	OM
Pneudraulics	1051	Thermal Relief Valve	OM
Pneudraulics	1058	Hydraulic Relief Valve	OM
Pneudraulics	1087	Hydraulic Relief Valve	CMM
Pneudraulics	1091	Relief Valve	CMM
Pneudraulics	1139-6-4500	Hydraulic Relief Valve	CMM
Pneudraulics	1139-6-5650	Hydraulic Relief Valve	CMM
Pneudraulics	1222-5-2350	Hydraulic Relief Valve	OM
Pneudraulics	1222-5-3600	Hydraulic Relief Valve	OM
Pneudraulics	1222-5-3600V	Hydraulic Relief Valve	OM
Pneudraulics	1227	Hydraulic Relief Valve, Engine Oil Cooler	OM
Pneudraulics	1422-1	Hydraulic Relief Valve	CMM
Pneudraulics	1441	Hydraulic Relief Valve	CMM
Pneudraulics	1441-1	Hydraulic Relief Valve	CMM
Pneudraulics	1643	Hydraulic Thermal Relief Valve	OM
Pneudraulics	1651	Pressure Relief Cartridge Valve	OM
Pneudraulics	1652	Pressure Relief Cartridge Valve	OM
Pneudraulics	1667	Engine Bleed Duct Relief Valve	OM
Pneudraulics	1669	Cartridge Relief Valve	OM
Pneudraulics	1669-1	Hydraulic Relief Valve	CMM
Pneudraulics	1686	Hydraulic Relief Valve	OM
Pneudraulics	1706-1	Hydraulic Relief Valve	CMM
Pneudraulics	1706-2	Hydraulic Relief Valve	CMM
Pneudraulics	1785-2	Hydraulic Relief Valve - Skydrol	CMM
Pneudraulics	1785-3	Hydraulic Relief Valve	CMM
Pneudraulics	1800	Hydraulic Relief Valve	CMM
Pneudraulics	1822-1	Pressure Relief Valve, Free Reverse Flow (Replaced by PN 4822-1)	CMM
Pneudraulics	1831-3	Hydraulic Relief Valve (Replaced by PN 1850)	CMM
Pneudraulics	1839	Hydraulic Thermal Relief Valve	CMM
Pneudraulics	1841	Hydraulic Relief Valve (Replaced by PN 1850)	CMM
Pneudraulics	1842	Pressure Relief Valve	CMM
Pneudraulics	1844	PRESSURE RELIEF VALVE	CMM
Pneudraulics	1849	Hydraulic Relief Valve	CMM

Pneudraulics	1850	Hydraulic Relief Valve (Replaces PN 1831-3 and 1841)	CMM
Pneudraulics	1C1130	Use NHA P/N 6360-2 for details	SUB-CMM
Pneudraulics	2084-19A	Pressure Reducing Valve	CMM
Pneudraulics	2084-21	Pressure Reducing Valve	CMM
Pneudraulics	2084-23	Pressure Reducing Valve	CMM
Pneudraulics	2084-27	Pressure Reducing Valve	CMM
Pneudraulics	2084-31	Pressure Reducing Valve	CMM
Pneudraulics	2084-33	Pressure Reducing Valve	CMM
Pneudraulics	2514-2	Low Pressure Hydraulic Relief Valve	CMM
Pneudraulics	2525-2	Hydraulic Relief / Bleed Valve	CMM
Pneudraulics	2525-2	Use NHA P/N 7140-7 for details	SUB-CMM
Pneudraulics	2525-2	Use NHA P/N 7459-3 for details	SUB-CMM
Pneudraulics	2525-2	Use NHA P/N 7470-1 for details	SUB-CMM
Pneudraulics	2530	Use NHA P/N 7301 for details	SUB-CMM
Pneudraulics	2530	Use NHA P/N 7302 for details	SUB-CMM
Pneudraulics	2530-1	Use NHA P/N 7301-1 for details	SUB-CMM
Pneudraulics	2530-1	Use NHA P/N 7302-1 for details	SUB-CMM
Pneudraulics	2576	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	2576	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	2576-1	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	2576-1	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	2576-2	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	2576-2	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	2577	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	2577	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	2577-1	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	2577-1	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	2577-1	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	2577-1	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	2590-1	Hydraulic Relief Valve	CMM
Pneudraulics	2607	Hydraulic Relief Valve	CMM
Pneudraulics	2612	Reservoir Relief Valve	CMM
Pneudraulics	2615	Center System Relief Valve	CMM
Pneudraulics	2619	Hydraulic Relief Valve	CMM
Pneudraulics	2623	Use NHA P/N 8196-5 for details	SUB-CMM
Pneudraulics	2623-1	Use NHA P/N 8210-5 for details	SUB-CMM

Pneudraulics, Inc.

FAA Certificated Repair

Station No.: PD6R469J

Capabilities List - ALL LISTINGS ARE ACCESSORY, CLASS I

**Authorized for use on Repair
Station Operations Specifications**
Ref: QSP 21.101 for use and modification
 *EASA release only part numbers

Pneudraulics	2623-1	Use NHA P/N 8210-6 for details	SUB-CMM
Pneudraulics	2623-1	Use NHA P/N 8231 for details	SUB-CMM
Pneudraulics	2623-1	Use NHA P/N 8210-4 for details	SUB-CMM
Pneudraulics	2623-1	Use NHA P/N 8210-3 for details	SUB-CMM
Pneudraulics	2623-11	Use NHA P/N 7589-4 for details	SUB-CMM
Pneudraulics	2623-3	Use NHA P/N 7550-2 for details	SUB-CMM
Pneudraulics	2623-4	Use NHA P/N 7550-3 for details	SUB-CMM
Pneudraulics	2623-4	Use NHA P/N 7550-4 for details	SUB-CMM
Pneudraulics	2623-5	Use NHA P/N 7551-1 for details	SUB-CMM
Pneudraulics	2623-6	Use NHA P/N 7551-5 for details	SUB-CMM
Pneudraulics	2623-6	Use NHA P/N 7551-6 for details	SUB-CMM
Pneudraulics	2623-6	Use NHA P/N 7551-9 for details	SUB-CMM
Pneudraulics	2623-6	Use NHA P/N 7551-10 for details	SUB-CMM
Pneudraulics	2623-6	Use NHA P/N 7551-7 for details	SUB-CMM
Pneudraulics	2623-7	Use NHA P/N 7583 for details	SUB-CMM
Pneudraulics	2626	Use NHA P/N 8207 for details	SUB-CMM
Pneudraulics	2627	Use NHA P/N 7544 for details	SUB-CMM
Pneudraulics	2627	Use NHA P/N 7498 for details	SUB-CMM
Pneudraulics	2627	Use NHA P/N 7504 for details	SUB-CMM
Pneudraulics	2627	Use NHA P/N 7514-1 for details	SUB-CMM
Pneudraulics	2627	Use NHA P/N 7445-4 for details	SUB-CMM
Pneudraulics	2627	Use NHA P/N 7447-4 for details	SUB-CMM
Pneudraulics	2627-502	Use NHA P/N 7514-5 for details	SUB-CMM
Pneudraulics	2627-502	Use NHA P/N 7544-3 for details	SUB-CMM
Pneudraulics	2633	Pressure Relief Valve	CMM
Pneudraulics	2634	Hydraulic Bleed / Relief Valve	CMM
Pneudraulics	2634-1	Hydraulic Bleed / Relief Valve	CMM
Pneudraulics	2634-1	Use NHA P/N 7468-2 for details	SUB-CMM
Pneudraulics	2634-1	Use NHA P/N 7468-3 for details	SUB-CMM
Pneudraulics	2634-902	Use NHA P/N 7468-9 for details	SUB-CMM
Pneudraulics	2634-902	Hydraulic Bleed / Relief Valve	CMM
Pneudraulics	2640	Pressure Relief Valve	CMM
Pneudraulics	2641	Hydraulic Reservoir Bleed/Relief Valve	CMM
Pneudraulics	2659	Use NHA P/N 7569 for details	SUB-CMM
Pneudraulics	2659	Use NHA P/N 7520-2 for details	SUB-CMM
Pneudraulics	2659-1	Use NHA P/N 7520-3 for details	SUB-CMM

Pneudraulics	2664	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	2672	Use NHA P/N 8257-3 for details	SUB-CMM
Pneudraulics	2673*	Hydraulic Bleed / Relief Valve Assembly	CMM
Pneudraulics	2677-3*	Hydraulic System Relief Valve Assembly	CMM
Pneudraulics	2677-5*	Hydraulic System Relief Valve Assembly	CMM
Pneudraulics	2678-103	Use NHA P/N 2677-5 for details	SUB-CMM
Pneudraulics	2678-103	Use NHA P/N 2677-3 for details	SUB-CMM
Pneudraulics	2679-1	Use NHA P/N 7563-32 for details	SUB-CMM
Pneudraulics	2679-1	Use NHA P/N 7561-12 for details	SUB-CMM
Pneudraulics	2682	Valve, Hydraulic, Thermal Relief	CMM
Pneudraulics	2683	VALVE PRESSURE RELIEF	CMM
Pneudraulics	2684	Crossover Pressure Relief Valve	CMM
Pneudraulics	2687	Relief Valve	CMM
Pneudraulics	2688	Use NHA P/N 7592 for details	SUB-CMM
Pneudraulics	2694	Reservoir Bleed / Relief Valve	CMM
Pneudraulics	2694	Use NHA P/N 7593-3 for details	SUB-CMM
Pneudraulics	2694	Use NHA P/N 7594-3 for details	SUB-CMM
Pneudraulics	3268	Use NHA P/N 8120 for details	SUB-CMM
Pneudraulics	3283-1	Hydraulic/Pneumatic, 3 Way, 2 Pos Toggle Valve	CMM
Pneudraulics	3285-1	Use NHA P/N 3360 for details	SUB-CMM
Pneudraulics	3285-2	Use NHA P/N 3383 for details	SUB-CMM
Pneudraulics	3343	3-Way, 2-Position Pilot Operated Valve	CMM
Pneudraulics	3349	Use NHA P/N 9604-1 for details	SUB-CMM
Pneudraulics	3349-1	Use NHA P/N 3395 for details	SUB-CMM
Pneudraulics	3349-1	Use NHA P/N 3359 for details	SUB-CMM
Pneudraulics	3349-1	Use NHA P/N 3353 for details	SUB-CMM
Pneudraulics	3349-1	Use NHA P/N 3362-3 for details	SUB-CMM
Pneudraulics	3349-2	Use NHA P/N 8214-4 for details	SUB-CMM
Pneudraulics	3353	Hydraulic Thermal Relief Valve 3349-1 Thrm Rlf Valve in CMM	CMM
Pneudraulics	3354	Pneumatic Operated Override Valve	CMM
Pneudraulics	3354	Use NHA P/N 8218 for details	SUB-CMM
Pneudraulics	3354	Use NHA P/N 8218-2 for details	SUB-CMM
Pneudraulics	3359	Hyd Dump/Thermal Relief Valve 3349-1 Thrm Rlf Valve in CMM	CMM
Pneudraulics	3360	(Restricted Use): Pressure Dump and Relief Valve	CMM
Pneudraulics	3362-3	Hydraulic Thermal Relief Valve 3349-1Thrm Rlf Valve in CMM	CMM

Pneudraulics	3363	Hydraulic Control Speedbrake Valve	CMM
Pneudraulics	3368-5	Hydr Standby Pump Select Valve	CMM
Pneudraulics	3370	Manual Selector Valve	CMM
Pneudraulics	3370-1	Manual Selector Valve	CMM
Pneudraulics	3378	Dump/Thermal Relief Valve	CMM
Pneudraulics	3379	Use NHA P/N 3378 for details	SUB-CMM
Pneudraulics	3383	Relief and Pressure Dump Valve	CMM
Pneudraulics	3385-3	Dump Valve	CMM
Pneudraulics	3386-3	Solenoid Operated Dump Valve	CMM
Pneudraulics	3389	Dump/Thermal Relief Valve	CMM
Pneudraulics	3394	Thermal Relief / Dump Valve	CMM
Pneudraulics	3395	Dump/Thermal Relief Valve	CMM
Pneudraulics	35844	Use NHA P/N 3758 for details	SUB-OM
Pneudraulics	35845	Use NHA P/N 3758 for details	SUB-OM
Pneudraulics	35846	Use NHA P/N 3758 for details	SUB-OM
Pneudraulics	3758	Pilot Solenoid Valve	OM
Pneudraulics	3760	Solenoid Valve	OM
Pneudraulics	3836-6	Normally Closed, 3-Way, 2-Position, Solenoid Operated Hydraulic Valve	CMM
Pneudraulics	3846	Solenoid Operated Shut-Off Valve	CMM
Pneudraulics	3862	Solenoid Valve , Starting Ejector	CMM
Pneudraulics	3936	Sol Operated Anti-Icing SOV N.O.	CMM
Pneudraulics	3956-2	Normally Closed, 2-Pos., 2-Way, Solenoid Operated Valve	CMM
Pneudraulics	4004-1	Hydraulic Thrust Reverser Selector Valve	CMM
Pneudraulics	4006	N.C. 2-P, 3-W Solenoid Operated Valve	CMM
Pneudraulics	4049	Use NHA P/N 4051-1 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4051-3 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4051-4 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4052-3 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4107-1 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4107-2 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4107-3 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4107-4 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4170 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4218 for details	SUB-CMM
Pneudraulics	4049	Use NHA P/N 4170-2 for details	SUB-CMM

Pneudraulics	4049	Use NHA P/N 4052-4 for details	SUB-CMM
Pneudraulics	4051	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4051-1	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	4051-1	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4051-3	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4051-3	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	4051-4	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4051-4	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	4051-4	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	4051-4	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	4052	Use NHA P/N 4052-1 for details	SUB-CMM
Pneudraulics	4052	Use NHA P/N 4052-2 for details	SUB-CMM
Pneudraulics	4052-1	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4052-1	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4052-1	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	4052-2	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	4052-2	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4052-2	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4052-3	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4052-3	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	4052-3	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	4052-3	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	4052-3	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	4052-4	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	4052-4	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	4052-4	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	4052-4	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	4052-4	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4065-1	N.C., 2-Position, 3-Way Solenoid Valve	CMM
Pneudraulics	4065-2	VALVE, SOLENOID, 3 WAY, 2-POSITION, N.C	CMM
Pneudraulics	4065-3	Solenoid Operated Valve 3 Way, 2 Pos, NC	CMM
Pneudraulics	4065-4	VALVE, SOLENOID, 3-WAY, 2-POSITION, N.C	CMM
Pneudraulics	4073	Normally Open, 2-Way, 2-Position, Solenoid Operated Valve	CMM
Pneudraulics	4082-2	Normally Open, 2-Way, 2-Position, Solenoid Operated Valve	CMM
Pneudraulics	4082-2	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4082-2	Use NHA P/N 8184-8 for details	SUB-CMM

Pneudraulics	4082-6	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	4082-6	Normally Open, 2-Way, 2-Position, Solenoid Operated Valve	CMM
Pneudraulics	4082-6	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	4082-6	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	4082-6	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	4083	Normally Open, 2-Way, 2-Position, Shut-Off Valve	CMM
Pneudraulics	4083-1	Normally Open, 2-Way, 2-Position, Shut-Off Valve	CMM
Pneudraulics	4085	Solenoid-Operated 3-Way Valve CMM 4951780 for 4085, 4085-1 and 4085-2	PCMM
Pneudraulics	4085-1	Solenoid-Operated 3-Way Valve CMM 4951780 for 4085, 4085-1 and 4085-2	PCMM
Pneudraulics	4085-2	Solenoid-Operated 3-Way Valve CMM 4951780 for 4085, 4085-1 and 4085-2	PCMM
Pneudraulics	4088	Normally Open, 2-Way, 2-Pos., Solenoid Operated Valve	CMM
Pneudraulics	4097-3	Normally Closed, 2-Position, 3-Way Solenoid Operated Valve	CMM
Pneudraulics	4098-3	2-Position, 3-Way Solenoid Operated Valve	CMM
Pneudraulics	4100-1	Use NHA P/N 4098-3 for details	SUB-CMM
Pneudraulics	4100-3	Use NHA P/N 4240 for details	SUB-CMM
Pneudraulics	4100-3	Use NHA P/N 4240-1 for details	SUB-CMM
Pneudraulics	4107-1	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4107-1	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	4107-1	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4107-2	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4107-2	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	4107-2	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4107-3	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4107-3	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	4107-4	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	4107-4	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4131	Solenoid Operated Valve 3 Way, 2 Pos, NC	CMM
Pneudraulics	4131-1	Solenoid Operated Valve 3 Way, 2 Pos, NC	CMM
Pneudraulics	4131-2	Solenoid Operated Valve 3 Way, 2 Pos, NC	CMM
Pneudraulics	4131-3	Solenoid Operated Valve 3 Way, 2 Pos, NC	CMM
Pneudraulics	4134	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	4134	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	4134-1	Use NHA P/N 8219 for details	SUB-CMM
Pneudraulics	4134-3	Use NHA P/N 8184-10 for details	SUB-CMM

Pneudraulics	4134-4	Use NHA P/N 8250-1 for details	SUB-CMM
Pneudraulics	4134-4	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	4134-4	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	4134-5	VALVE, SOLENOID, OPER., 2 WAY-2 POS., N.O	CMM
Pneudraulics	4138	Use NHA P/N 8208 for details	SUB-CMM
Pneudraulics	4138	Use NHA P/N 8207 for details	SUB-CMM
Pneudraulics	4140-3	Hydraulic PTU Select Valve Assembly	CMM
Pneudraulics	4140-7	Hydraulic PTU Select Valve Assembly	CMM
Pneudraulics	4140-9	Hydraulic PTU Select Valve Assembly	CMM
Pneudraulics	4142	Solenoid Operated Valve 3 Way, 2 Pos, NC	CMM
Pneudraulics	4144	Use NHA P/N 8206-2 for details	SUB-CMM
Pneudraulics	4151	Two-Way, Two-Position, Normally Open Solenoid Valve	CMM
Pneudraulics	4152	N.C. 2-P, 3-W Solenoid Operated Valve	CMM
Pneudraulics	4155-2	Use NHA P/N 4140-7 for details	SUB-CMM
Pneudraulics	4155-2	Use NHA P/N 4140-3 for details	SUB-CMM
Pneudraulics	4155-2	Use NHA P/N 8214-4 for details	SUB-CMM
Pneudraulics	4155-3	Use NHA P/N 4190-1 for details	SUB-CMM
Pneudraulics	4155-3	Use NHA P/N 4203-1 for details	SUB-CMM
Pneudraulics	4155-3	Use NHA P/N 4187-1 for details	SUB-CMM
Pneudraulics	4155-901	Use NHA P/N 4140-9 for details	SUB-CMM
Pneudraulics	4155-902	Use NHA P/N 4304-2 for details	SUB-CMM
Pneudraulics	4170	Use NHA P/N 8218 for details	SUB-CMM
Pneudraulics	4170	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4170-2	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4170-2	Use NHA P/N 8218-2 for details	SUB-CMM
Pneudraulics	4174	Use NHA P/N 4004-1 for details	SUB-CMM
Pneudraulics	4180-1		CMM
Pneudraulics	4186-1	Normally Closed, 2-Position, 3-Way Solenoid Operated Hydraulic Valve	CMM
Pneudraulics	4187-1	Hydraulic PTU Select Valve Solenoid Operated	CMM
Pneudraulics	4188-1	Shut off Valve Assembly	CMM
Pneudraulics	4188-2	Hydraulic Relief Valve	CMM
Pneudraulics	4190-1	Hydraulic PTU Select Valve Solenoid Operated	CMM
Pneudraulics	4193-2		CMM
Pneudraulics	4200-1	VALVE, SOLENOID, 3W-2P N.C.	CMM
Pneudraulics	4200-11	VALVE, SOLENOID 3 WAY 2 POS N.C.	CMM

Pneudraulics	4200-3	VALVE, SOLENOID, 3W-2P N.C.	CMM
Pneudraulics	4203-1	Hydr PTU Select Valve Solenoid Operated	CMM
Pneudraulics	4215-1	Normally Open, 2-position, 2-Way Solenoid Operated Valve	CMM
Pneudraulics	4215-1	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4215-2	Normally Open, 2-position, 2-Way Solenoid Operated Valve	CMM
Pneudraulics	4216-2	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4216-2	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4216-3	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4216-3	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4217-1	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4218	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4218-1	3-Position, 4-Way Solenoid Operated Valve	CMM
Pneudraulics	4218-1	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4219-1	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4220-1	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4221	Use NHA P/N 8245 for details	SUB-CMM
Pneudraulics	4222	Use NHA P/N 8245 for details	SUB-CMM
Pneudraulics	4222	Solenoid Operated Thrust Reverser Isolation Valve	CMM
Pneudraulics	4227	Pump Unloader Valve Solenoid Valve	CMM
Pneudraulics	4234	Use NHA P/N 8247-3 for details	SUB-CMM
Pneudraulics	4234-5	Use NHA P/N 8247-5 for details	SUB-CMM
Pneudraulics	4235	Use NHA P/N 4218-1 for details	SUB-CMM
Pneudraulics	4235	Use NHA P/N 4216-3 for details	SUB-CMM
Pneudraulics	4235	Use NHA P/N 4216-2 for details	SUB-CMM
Pneudraulics	4236	Use NHA P/N 4222 for details	SUB-CMM
Pneudraulics	4240	2-Position, 3-Way Solenoid Operated Valve	CMM
Pneudraulics	4240-1	2-Position, 3-Way Solenoid Operated Valve	CMM
Pneudraulics	4240-3	2-Position, 3-Way Solenoid Operated Valve	CMM
Pneudraulics	4251	Use NHA P/N 8257-3 for details	SUB-CMM
Pneudraulics	4252	Use NHA P/N 8257-3 for details	SUB-CMM
Pneudraulics	4254	Normally Open, 2-Way, 2-Position, ACMP Unloader Valve	CMM
Pneudraulics	4255	PTU Select, Hydraulic Valve Assembly	CMM
Pneudraulics	4256	Use NHA P/N 4255 for details	SUB-CMM
Pneudraulics	4260-5	Normally Open, 2-Position Solenoid Valve	CMM
Pneudraulics	4260-7	Normally Open, 2-Position Solenoid Valve	CMM
Pneudraulics	4260-9	Valve, Solenoid, 2-Position, Normally Open	CMM

Pneudraulics	4262-1*	Hydraulic PTU Select Valve Assembly	CMM
Pneudraulics	4264	Use NHA P/N 8262-7 for details	SUB-CMM
Pneudraulics	4265	Use NHA P/N 8266-3 for details	SUB-CMM
Pneudraulics	4267	Use NHA P/N 4262-1 for details	SUB-CMM
Pneudraulics	4270-1	Valve, Solenoid Operated, Landing Gear Control	CMM
Pneudraulics	4271-1	Solenoid Operated Flaps Control Valve	CMM
Pneudraulics	4273	Use NHA P/N 4188-1 for details	SUB-CMM
Pneudraulics	4288	MAIN ENTRY DOOR CONTROL VALVE	CMM
Pneudraulics	4304-2	PTU Select Valve	CMM
Pneudraulics	4340	Valve, Solenoid, 3-Way, 2-Position, N.C.	CMM
Pneudraulics	4527-1	Free Reverse Flow Ballanced Outlet Relief Valve	CMM
Pneudraulics	4538	Hydraulic Priority Rlf Cartridge Valve	OM
Pneudraulics	4549	Hydraulic Priority Relief Cartridge Valves	OM
Pneudraulics	4556	Hydraulic Priority Valve	OM
Pneudraulics	4567	Priority Cartridge Valve	OM
Pneudraulics	4571	Hydraulic Priority Valve	OM
Pneudraulics	4588-6	Hydraulic Priority Valve	OM
Pneudraulics	4614	Free Reverse Flow, Balanced Outlet, Relief Valve	CMM
Pneudraulics	4618	Hydraulic Priority Relief Cartridge Valves	OM
Pneudraulics	4619	Relief Valve, Balanced Outlet Free Reverse Flow	CMM
Pneudraulics	4619-3	Relief Valve, Balanced Outlet Free Reverse Flow	CMM
Pneudraulics	4622	Free Reverse Flow, Balanced Outlet, Relief Valve	CMM
Pneudraulics	4626-1	Hydraulic Priority Valve	CMM
Pneudraulics	4638	Valve, Relief, Balanced Outlet Free Reverse Flow	CMM
Pneudraulics	4638-1	Valve, Relief, Balanced Outlet Free Reverse Flow	CMM
Pneudraulics	4661	Valve, Relief Balance Outlet Free Reverse Flow	CMM
Pneudraulics	4663	Hydraulic Balanced Relief Valve	CMM
Pneudraulics	4663-3	Hydraulic Balanced Relief Valve	CMM
Pneudraulics	4665-2	Hydraulic Balanced Relief Valve	CMM
Pneudraulics	4669-1	Hydraulic Balanced Relief Valve Free Reverse Flow	CMM
Pneudraulics	4669-5	Hydraulic Balanced Relief Valve Free Reverse Flow	CMM
Pneudraulics	4673	Hydraulic Priority Valve 3.0 GPM	CMM
Pneudraulics	4675-3	Hydraulic Balanced Relief Valve	CMM
Pneudraulics	4679-3	Hydraulic Priority Valve	CMM
Pneudraulics	4681	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	4682	Hydraulic Priority Valve	CMM

Pneudraulics	4689	Hydraulic Priority Valve	CMM
Pneudraulics	4690	Hydraulic Bootstrap Priority Valve	CMM
Pneudraulics	4691	Hydraulic High Lift Priority Valve	CMM
Pneudraulics	4692	MLG Hydraulic Priority Valve	CMM
Pneudraulics	4698	Hydraulic Priority Valve	CMM
Pneudraulics	4698-3	Hydraulic Priority Valve	CMM
Pneudraulics	4698-4	Hydraulic Priority Valve	CMM
Pneudraulics	4702	Hydraulic Priority Valve	CMM
Pneudraulics	4703	Bootstrap Priority Valve	CMM
Pneudraulics	4706	Hydraulic Priority Valve	CMM
Pneudraulics	4707	Hydraulic Priority Valve	CMM
Pneudraulics	4720	Component Maintenance Manual	CMM
Pneudraulics	4822-1	Free Reverse Flow, Pressure Relief Valve	CMM
Pneudraulics	5057	Hydraulic Autobrake Shuttle Valve	OM
Pneudraulics	5057-1	Autobrake Hydraulic Shuttle Valve	OM
Pneudraulics	5059-2	Hydraulic Shuttle Valves (Replaced by 5059-4,5060-5/-6)	CMM
Pneudraulics	5059-3	Hydraulic Shuttle Valve	CMM
Pneudraulics	5059-4	VALVE, HYDRAULIC SHUTTLE	CMM
Pneudraulics	5059-5	VALVE, HYDRAULIC SHUTTLE	CMM
Pneudraulics	5060-3	Hydraulic Shuttle Valves (Replaced by 5059-4,5060-5/-6)	CMM
Pneudraulics	5060-4	Hydraulic Shuttle Valves (Replaced by 5059-4,5060-5/-6)	CMM
Pneudraulics	5060-5	VALVE, HYDRAULIC SHUTTLE	CMM
Pneudraulics	5060-6	VALVE, HYDRAULIC SHUTTLE	CMM
Pneudraulics	5066-5	Manual Reset Hydraulic Dump Valve	CMM
Pneudraulics	5073	Hydraulic Shuttle Valve	CMM
Pneudraulics	5084	Hydraulic Shuttle Valve	CMM
Pneudraulics	5084-1	Hydraulic Shuttle Valve	CMM
Pneudraulics	5113	Use NHA P/N 8189 for details	SUB-CMM
Pneudraulics	5118	Hydraulic Shuttle Valve	CMM
Pneudraulics	5125-2		CMM
Pneudraulics	5128-5	Hydraulic Shuttle Valve	CMM
Pneudraulics	5128-6	Hydraulic Shuttle Valve	CMM
Pneudraulics	5145-1	Hydraulic Shuttle Valve	CMM
Pneudraulics	5156	Hydraulic Shuttle Valve	CMM
Pneudraulics	6105	Hydraulic Fuse Assembly	CMM
Pneudraulics	6105-1	Hydraulic Fuse Assembly	CMM

Pneudraulics	6105-1	Use NHA P/N 6188-2 for details	SUB-CMM
Pneudraulics	6114-5	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6114-6	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6114-7	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6147-1	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6147-2	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6147-3	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6168	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6169-3	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6170	Hydr Flow Regulator Cartridge Valve	CMM
Pneudraulics	6172	Hydraulic Flow Regulator Cartridge Valve	CMM
Pneudraulics	6174-1	Cartridge Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6174-2	Cartridge Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6177	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6178	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6179	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6185-1	Hydraulic Volumetric Fuse with Bypass	CMM
Pneudraulics	6188	Hydraulic Fuse Assembly	CMM
Pneudraulics	6188-2	Hydraulic Fuse Assembly	CMM
Pneudraulics	6190	Hydraulic Volumetric Fuse With Bypass	OM
Pneudraulics	6190-1	Hydraulic Volumetric Fuse with Bypass	OM
Pneudraulics	6190-3	Hydraulic Volumetric Fuse with Bypass	CMM
Pneudraulics	6191-1	Hydraulic Trim Cylinder Fuse	CMM
Pneudraulics	6191-2	Hydraulic Trim Cylinder Fuse	CMM
Pneudraulics	6193-1	Use NHA P/N 6360-2 for details	SUB-CMM
Pneudraulics	6194	Hydraulic Fuse	CMM
Pneudraulics	6195	Use NHA P/N 6194 for details	SUB-CMM
Pneudraulics	6197	Hydraulic Volumetric Fuse With Bypass	CMM
Pneudraulics	6197-1	Hydraulic Volumetric Fuse With Bypass	CMM
Pneudraulics	6211-1	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6211-2	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6212	Hydraulic Quantity Measuring Fuse With Bypass	CMM
Pneudraulics	6213-3	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6213-4	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6215-4	Hydraulic Flow Regulator Cartridge Valves	CMM
Pneudraulics	6215-5	Hydraulic Flow Regulator Cartridge Valves	CMM

Pneudraulics, Inc.

FAA Certificated Repair

Station No.: PD6R469J

Capabilities List - ALL LISTINGS ARE ACCESSORY, CLASS I

**Authorized for use on Repair
Station Operations Specifications
Ref: QSP 21.101 for use and modification
*EASA release only part numbers**

Pneudraulics	6216-1	Hydraulic Flow Regulator Cartridge Valves	CMM
Pneudraulics	6249	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6252	Hydraulic Quantity Measuring Fuse With Bypass	CMM
Pneudraulics	6257	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6268-10	Hydraulic Flow Regulator,Cartridge Valve (Replaces 6268-8)	CMM
Pneudraulics	6268-12	Hydraulic Flow Regulator,Cartridge Valve (Replaces 6268-8)	CMM
Pneudraulics	6268-8	Hydraulic Easy On Flow Regulator, Cartridge Valve (Replaced by 6268-10/-12) 6268-10/-12)	CMM
Pneudraulics	6271	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6271-1	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6272-1	Volumetric Hydraulic Fuse	CMM
Pneudraulics	6273-1	Volumetric Hydraulic Fuse	CMM
Pneudraulics	6273-5	Volumetric Hydraulic Fuse	CMM
Pneudraulics	6274-1	Hydraulic Volumetric Fuse	CMM
Pneudraulics	6279-1	Type I Automatic Quantity Measuring Hydraulic Fuse	CMM
Pneudraulics	6288	Hydraulic Volumetric Fuse With Bypass	CMM
Pneudraulics	6305		CMM
Pneudraulics	6338-1	RH System Hydraulic Reservoir	CMM
Pneudraulics	6349-1	Hydraulic Fuse	CMM
Pneudraulics	6350	Hydraulic Volumetric Fuse with Bypass	CMM
Pneudraulics	6360-2	Hydraulic Trim Cylinder Fuse	CMM
Pneudraulics	6362	Hydraulic Volumetric FuseWith Bypass (Brake control System)	CMM
Pneudraulics	6364	Use NHA P/N 8208 for details	SUB-CMM
Pneudraulics	6366	Hydraulic Quantity Measuring Fuse With Bypass	CMM
Pneudraulics	6373-1	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6373-2	Hydraulic Flow Regulator Valve	CMM
Pneudraulics	6376	Volumetric with Bypass - Hydraulic Fuse	CMM
Pneudraulics	6390	Damped Check Valve	CMM
Pneudraulics	6392	Use NHA P/N 8219 for details	SUB-CMM
Pneudraulics	6392-3	Use NHA P/N 8247-3 for details	SUB-CMM
Pneudraulics	6392-3	Use NHA P/N 8247-5 for details	SUB-CMM
Pneudraulics	6402*	PTU Flow Control Valve	CMM
Pneudraulics	6411	Hydraulic Volumetric Fuse with Bypass	CMM
Pneudraulics	6412-1	Hydraulic Quantity Measuring Fuse With Bypass	CMM
Pneudraulics	6421-1	FUSE-HYDRAULIC QUAN.	CMM
Pneudraulics	6438-1	Hydraulic Shuttle Valve	CMM

Pneudraulics	6438-1	Use NHA P/N 5145-1 for details	SUB-CMM
Pneudraulics	6444	Quantity Measuring Hydraulic Fuse with Bypass	CMM
Pneudraulics	6472	VALVE, DAMPED OPENING	CMM
Pneudraulics	6474	Fuse, Hydraulic, Quantity Measuring With Bypass	CMM
Pneudraulics	7140-7	Self-Pressurizing Reservoir	CMM
Pneudraulics	7301	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7301-1	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7302	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7302-1	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7303	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7303-1	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7313-1	Hydraulic Compesator	CMM
Pneudraulics	7313-2	Hydraulic Compesator	CMM
Pneudraulics	7319	Hydraulic Actuator	CMM
Pneudraulics	7319-2	Hydraulic Actuator	CMM
Pneudraulics	7401-3	Hydraulic Bootstrap Reservoir	CMM
Pneudraulics	7437		CMM
Pneudraulics	7438-4	Hydraulic Nose Gear Steering Swivel Assembly	CMM
Pneudraulics	7445-4	Hydr Reservoir Assy, Sys 2 & 1 2627 Relief Valve in CMM 9560-9/-11 Ind Assy in CMM	CMM
Pneudraulics	7446-4	Hydr Reservoir Assy, Sys 3 9560-10 Indicator Assy in CMM	CMM
Pneudraulics	7447-4	Hydr Reservoir Assy, Sys 2 & 1 2627 Relief Valve in CMM 9560-9/-11 Ind Assy in CMM	CMM
Pneudraulics	7459-3	Hydraulic Bootstrap Reservoir	CMM
Pneudraulics	7468-2	System 3 Hydraulic Reservoir Assembly	CMM
Pneudraulics	7468-3	System 3 Hydraulic Reservoir Assembly	CMM
Pneudraulics	7468-9	System 3 Hydraulic Reservoir Assembly	CMM
Pneudraulics	7469-1	Actuator, Hydraulic, MLG Inboard Door	CMM
Pneudraulics	7470-1	Hydraulic Bootstrap Reservoir	CMM
Pneudraulics	7498	Reservoir Assembly, Hydraulic, System 2	CMM
Pneudraulics	7498-3	Reservoir Assembly, Hydraulic, System 2	CMM
Pneudraulics	7499	Reservoir Assembly, Hydraulic, System 3	CMM
Pneudraulics	7499-3	Reservoir Assembly, Hydraulic, System 3	CMM
Pneudraulics	7504	Reservoir Assembly, Hydraulic, System 1	CMM
Pneudraulics	7504-3	Reservoir Assembly, Hydraulic, System 1	CMM
Pneudraulics	7508-2	Link Actuator	CMM
Pneudraulics	7514-1	750 Cubic Inch Hydraulic Reservoir Assembly	CMM

Pneudraulics	7514-5	750 Cubic Inch Hydraulic Reservoir Assembly	CMM
Pneudraulics	7520-2	700 Cu. In. Hydraulic Bootstrap Reservoir	CMM
Pneudraulics	7520-3	700 Cu. In. Hydraulic Bootstrap Reservoir	CMM
Pneudraulics	7523-3	Thrust Reverser Actuator	CMM
Pneudraulics	7526	Actuator, Landing Gear Door	CMM
Pneudraulics	7535-6	Actuator, Locking,Main Landing Gear	CMM
Pneudraulics	7535-7	Actuator, Locking,Main Landing Gear	CMM
Pneudraulics	7535-8	Actuator, Locking,Main Landing Gear	CMM
Pneudraulics	7544	525 CUBIC INCH HYDRAULIC RESERVOIR	CMM
Pneudraulics	7544-3	525 CUBIC INCH HYDRAULIC RESERVOIR	CMM
Pneudraulics	7550-2	Hydraulic Accumulator	CMM
Pneudraulics	7550-3	Hydraulic Accumulator	CMM
Pneudraulics	7550-4	Hydraulic Accumulator	CMM
Pneudraulics	7551-1	Hydraulic Accumulator	CMM
Pneudraulics	7551-10	Hydraulic Accumulator	CMM
Pneudraulics	7551-5	Hydraulic Accumulator	CMM
Pneudraulics	7551-6	Hydraulic Accumulator	CMM
Pneudraulics	7551-7	Hydraulic Accumulator	CMM
Pneudraulics	7551-9	Hydraulic Accumulator	CMM
Pneudraulics	7558-12*	Reservoir Assembly, Hydraulic, 750 Cubic Inch	CMM
Pneudraulics	7559-21*	375 Cubic Inch Hydraulic Reservoir Assembly	CMM
Pneudraulics	7559-22*	375 Cubic Inch Hydraulic Reservoir Assembly	CMM
Pneudraulics	7561-12	750 Cubic Inch Hydraulic Reservoir Assembly	CMM
Pneudraulics	7562-22	RESERVOIR, ASSEMBLY, HYDRAULIC, 930 CU IN	CMM
Pneudraulics	7563-32	525 cu. in Hydraulic Reservoir Assembly	CMM
Pneudraulics	7565-3*	Accumulator with LVDT Sensor	CMM
Pneudraulics	7565-4*	Accumulator With LVDT Sensor	CMM
Pneudraulics	7569	Bootstrap Hydraulic Reservoir	CMM
Pneudraulics	7578	Right Hydraulic System Reservoir Assembly	CMM
Pneudraulics	7579	250 cubic inch Left Hydraulic System Reservoir Assembly	CMM
Pneudraulics	7583	Hydraulic Accumulator	CMM
Pneudraulics	7589-4*	Accumulator Assembly, Hydraulic, 1.6 Liter	CMM
Pneudraulics	7592	250 CUBIC INCH HYDRAULIC RESERVOIR	CMM
Pneudraulics	7593-3	RESERVOIR, HYDRAULIC, 525 CUBIC INCHES	CMM
Pneudraulics	7594-3	610 Cubic Inch Hydraulic Reservoir	CMM
Pneudraulics	7598-2		CMM

Pneudraulics	7631	50 Cubic Inches Accumulator	CMM
Pneudraulics	7631-1	50 Cubic Inches Accumulator	CMM
Pneudraulics	7631-2	50 Cubic Inches Accumulator	CMM
Pneudraulics	7642	Accumulator, 50 Cubic Inches	CMM
Pneudraulics	7643	75 Cubic Inch Accumulator	CMM
Pneudraulics	7644	ACCUMULATOR, 75 CU. IN.	CMM
Pneudraulics	7662	RESERVOIR ASSEMBLY, SYSTEM 1 (500 CU IN)	CMM
Pneudraulics	7663	RESERVOIR ASSEMBLY, SYSTEM 2 (1400 CU IN)	CMM
Pneudraulics	7664	RESERVOIR ASSEMBLY, SYSTEM 3 (1150 CU IN)	CMM
Pneudraulics	7665-3		CMM
Pneudraulics	7679-1	MLG-DOOR ACTUATOR AS	CMM
Pneudraulics	7691	Accumulator, 25 CU IN	CMM
Pneudraulics	7700-3	ACTUATOR, GROUND SPOILER	CMM
Pneudraulics	7701-2		CMM
Pneudraulics	7701-3		CMM
Pneudraulics	7702-2	ACTUATOR, ROLL SPOILER, RH	CMM
Pneudraulics	7702-3		CMM
Pneudraulics	7707-1	EMERGENCY MLG EXT ACT	CMM
Pneudraulics	7708-1	ACTUATOR, HYDRAULIC, MAIN LANDING GEAR DOOR	CMM
Pneudraulics	7714-3	DOOR UPLOCK ACTUATOR	CMM
Pneudraulics	7715-3	MLG UPLOCK ACTUATOR, LH	CMM
Pneudraulics	7717-3	MLG UPLOCK ACTUATOR, RH	CMM
Pneudraulics	7753-1		CMM
Pneudraulics	7765-2		CMM
Pneudraulics	80788	Use NHA P/N 8269-1 for details	SUB-CMM
Pneudraulics	8120	Hydraulic Accumulator Manifold	CMM
Pneudraulics	8121	Hydraulic Snubbing Valve	CMM
Pneudraulics	8184-10	Hydraulic Manifold Assembly	CMM
Pneudraulics	8184-12	Hydraulic Manifold Assembly	CMM
Pneudraulics	8184-14	Hydraulic Manifold Assembly	CMM
Pneudraulics	8184-4	Hydraulic Manifold Assembly	CMM
Pneudraulics	8184-6	Hydraulic Manifold Assembly	CMM
Pneudraulics	8184-8	Hydraulic Manifold Assembly	CMM
Pneudraulics	8189	Shuttle Valve Module 5113 Shuttle Valve in CMM	CMM
Pneudraulics	8196-4	Emergency/Parking Brake Valve 2623 Thermal Rlf Valve in CMM	CMM

Pneudraulics	8196-5	Emergency/Parking Brake Valve 2623 Thermal Rlf Valve in CMM	CMM
Pneudraulics	8206-2	Hydraulic Slat Control Valve	CMM
Pneudraulics	8207	Relief - Unloading Valve	CMM
Pneudraulics	8208	PTU Controller	CMM
Pneudraulics	8210-3	Emergency Parking Brake Valve Assembly	CMM
Pneudraulics	8210-4	Emergency Parking Brake Valve Assembly	CMM
Pneudraulics	8210-5	Emergency Parking Brake Valve Assembly	CMM
Pneudraulics	8210-6	Emergency Parking Brake Valve Assembly	CMM
Pneudraulics	8212		CMM
Pneudraulics	8214-11	Hydraulic Accumulator Isolation Valve Assembly	CMM
Pneudraulics	8214-4	Hydraulic Accumulator Isolation Valve Assembly	CMM
Pneudraulics	8218	Hydraulic Manifold Assembly	CMM
Pneudraulics	8218-2	Hydraulic Manifold Assembly	CMM
Pneudraulics	8219	Hydr Flow Limiter Valve, Sol Oprd 4134-1 2-W, 2-P,NO Solv in CMM 6392 Flow Regulator in CMM	CMM
Pneudraulics	8231	Emergency Parking/Brake Valve 2623-1 Thermal Rlf Valve in CMM	CMM
Pneudraulics	8244-1	Hydraulic Manifold Assembly	CMM
Pneudraulics	8244-2	Hydraulic Manifold Assembly	CMM
Pneudraulics	8245	Thrust Reverser Manifold	CMM
Pneudraulics	8247-3	Valve, Flow Limiter, Solenoid Operated	CMM
Pneudraulics	8247-5	Valve, Flow Limiter, Solenoid Operted	CMM
Pneudraulics	8250-1	Hydraulic Manifold Assembly	CMM
Pneudraulics	8250-2	Hydraulic Manifold Assembly	CMM
Pneudraulics	8250-3	Hydraulic Manifold Assembly	CMM
Pneudraulics	8250-4	MANIFOLD ASSY, HYDRAULIC	CMM
Pneudraulics	8257-3	Landing Gear Manifold	CMM
Pneudraulics	8262-7		CMM
Pneudraulics	8266-3	Steering Reserve Isolation Valve	CMM
Pneudraulics	8267	Handpump	CMM
Pneudraulics	8267-1	Handle Assy	CMM
Pneudraulics	8267-11	Han dpump	CMM
Pneudraulics	8269-1	Brake - Power Valve	CMM
Pneudraulics	8269-2	Brake - Power Valve	CMM
Pneudraulics	8271-3	CONTROL MANIFOLD ASSY, FLAPS & LDG GEAR	CMM
Pneudraulics	8272-1	Solenoid Operate Isolation Valve Assembly	CMM

Pneudraulics	8273-5	Main Landing Gear Control Manifold Assembly	CMM
Pneudraulics	8274-5	Nose Landing Gear Control Manifold Assembly	CMM
Pneudraulics	8305	MLG CONTROL MANIFOLD	CMM
Pneudraulics	8306	NLG CONTROL MANIFOLD	CMM
Pneudraulics	8319-2	SPOILER MANIFOLD, INBOARD	CMM
Pneudraulics	8320-21	SPOILER MANIFOLD, MID & OUTBOARD, LH	CMM
Pneudraulics	8320-22	SPOILER MANIFOLD, MID & OUTBOARD, RH	CMM
Pneudraulics	8321-2	DUAL EMERGENCY/PARKING BRAKE VALVE	CMM
Pneudraulics	8324-4	MANIFOLD, HYDRAULIC LANDING GEAR CONTROL	CMM
Pneudraulics	8325-2	MANIFOLD, HYDRAULIC SYSTEM FILTER	CMM
Pneudraulics	8327-3	MANIFOLD, HYDRAULIC, SPOILER ACCUMULATOR	CMM
Pneudraulics	8328-2	SPOILER ISOLATION MANIFOLD	CMM
Pneudraulics	8342	EMERGENCY/PARK BRAKE VALVE	CMM
Pneudraulics	9394	Hydraulic Pressure Operated Check Valve	OM
Pneudraulics	9416-4	Use NHA P/N 7303 for details	SUB-CMM
Pneudraulics	9416-4	Use NHA P/N 7303-1 for details	SUB-CMM
Pneudraulics	9416-5	Use NHA P/N 7301 for details	SUB-CMM
Pneudraulics	9416-6	Use NHA P/N 7302 for details	SUB-CMM
Pneudraulics	9416-6	Use NHA P/N 7302-1 for details	SUB-CMM
Pneudraulics	9416-7	Use NHA P/N 7301-1 for details	SUB-CMM
Pneudraulics	9503	Pneumatic Operated Dump Valve	CMM
Pneudraulics	9503-1	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	9503-1	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	9503-1	Pneumatic Operated Dump Valve	CMM
Pneudraulics	9503-2	Pneumatic Operated Dump Valve	CMM
Pneudraulics	9503-2	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	9503-2	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	9504	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	9504	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	9504-1	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	9505	Use NHA P/N 8184-6 for details	SUB-CMM
Pneudraulics	9505	Use NHA P/N 8184-8 for details	SUB-CMM
Pneudraulics	9505-1	Use NHA P/N 8184-10 for details	SUB-CMM
Pneudraulics	9505-1	Use NHA P/N 8250-3 for details	SUB-CMM
Pneudraulics	9505-1	Use NHA P/N 8250-2 for details	SUB-CMM
Pneudraulics	9505-1	Use NHA P/N 8250-1 for details	SUB-CMM

Pneudraulics	9527	Waste System Drain Valve Assy (Replaced by PN 9527-1)	CMM
Pneudraulics	9527-1	Waste System Drain Valve Assy (Replaces PN 9527)	CMM
Pneudraulics	9527-10	Waste System Drain Valve Assy (Replaces PN 9527)	CMM
Pneudraulics	9527-3	Waste System Drain Valve Assy (Replaces PN 9527)	CMM
Pneudraulics	9560-10	Use NHA P/N 7446-4 for details	SUB-CMM
Pneudraulics	9560-11	Use NHA P/N 7447-4 for details	SUB-CMM
Pneudraulics	9560-9	Use NHA P/N 7445-4 for details	SUB-CMM
Pneudraulics	9569	Waste System Drain Valve Assy	CMM
Pneudraulics	9570-2	Hydraulic Isolation Valve Assembly	CMM
Pneudraulics	9571-2	Actuator, Steering, Nose Wheel	CMM
Pneudraulics	9589	Use NHA P/N 7468-2 for details	SUB-CMM
Pneudraulics	9589-1	Use NHA P/N 7468-3 for details	SUB-CMM
Pneudraulics	9589-901	Use NHA P/N 7468-9 for details	SUB-CMM
Pneudraulics	9590	Use NHA P/N 7499 for details	SUB-CMM
Pneudraulics	9590	Use NHA P/N 7498 for details	SUB-CMM
Pneudraulics	9590	Use NHA P/N 7544 for details	SUB-CMM
Pneudraulics	9590-301	Use NHA P/N 7544-3 for details	SUB-CMM
Pneudraulics	9591	Use NHA P/N 7504 for details	SUB-CMM
Pneudraulics	9593-2	Restrictor Valve Assembly	CMM
Pneudraulics	9593-3	Restrictor Valve Assembly	CMM
Pneudraulics	9601-1	Use NHA P/N 7514-1 for details	SUB-CMM
Pneudraulics	9601-501	Use NHA P/N 7514-5 for details	SUB-CMM
Pneudraulics	9602	Intensifier	CMM
Pneudraulics	9604-1	Switching Valve	CMM
Pneudraulics	9612	Use NHA P/N 7520-2 for details	SUB-CMM
Pneudraulics	9612-1	Use NHA P/N 7520-3 for details	SUB-CMM
Pneudraulics	9613	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	9615	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	9615	Pneumatic Operated Dump Valve	CMM
Pneudraulics	9618	Use NHA P/N 8244-1 for details	SUB-CMM
Pneudraulics	9625-1	Use NHA P/N 8257-3 for details	SUB-CMM
Pneudraulics	9626-1	Use NHA P/N 7561-12 for details	SUB-CMM
Pneudraulics	9628-1	Use NHA P/N 7563-32 for details	SUB-CMM
Pneudraulics	9629	Use NHA P/N 7561-12 for details	SUB-CMM
Pneudraulics	9629	Use NHA P/N 7563-32 for details	SUB-CMM
Pneudraulics	9630	Use NHA P/N 7563-32 for details	SUB-CMM

Pneudraulics	9630	Use NHA P/N 7561-12 for details	SUB-CMM
Pneudraulics	9631-1	Use NHA P/N 7558-12 for details	SUB-CMM
Pneudraulics	9632-1	Use NHA P/N 7559-22 for details	SUB-CMM
Pneudraulics	9632-1	Use NHA P/N 7559-21 for details	SUB-CMM
Pneudraulics	9636-3	Heat Exchanger Bypass Valve	CMM
Pneudraulics	9638-3	Cartridge Valve, Bypass, Heat Exchange (HX)	CMM
Pneudraulics	9638-5	Cartridge Valve, Bypass, Heat Exchange (HX)	CMM
Pneudraulics	9641	Use NHA P/N 7569 for details	SUB-CMM
Pneudraulics	9642	Heat Exchanger Bypass Valve	CMM
Pneudraulics	9642-5	Heat Exchanger Bypass Valve	CMM
Pneudraulics	9642-7	Heat Exchanger Bypass Valve	CMM
Pneudraulics	9643	Unloading Relief Valve	CMM
Pneudraulics	9643-1	Unloading Relief Valve	CMM
Pneudraulics	9644-7	Heat Exchanger Bypass Valve	CMM
Pneudraulics	9651	610 CUBIC INCH INDICATOR ASSEMBLY	CMM
Pneudraulics	9651	Use NHA P/N 7594-3 for details	SUB-CMM
Pneudraulics	9652-102	Use NHA P/N 7593-3 for details	SUB-CMM
Pneudraulics	9652-102	525 CUBIC INCH INDICATOR ASSEMBLY	CMM
Pneudraulics	9653	250 CUBIC INCH INDICATOR ASSEMBLY	CMM
Pneudraulics	9653	Use NHA P/N 7592 for details	SUB-CMM
Pneudraulics	9654	Use NHA P/N 7592 for details	SUB-CMM
Pneudraulics	9654	Use NHA P/N 7594-3 for details	SUB-CMM
Pneudraulics	9654	Use NHA P/N 7593-3 for details	SUB-CMM
Pneudraulics	9655	Use NHA P/N 7593-3 for details	SUB-CMM
Pneudraulics	9655	Use NHA P/N 7594-3 for details	SUB-CMM
Pneudraulics	9655	Use NHA P/N 7592 for details	SUB-CMM
Pneudraulics	9655	Temperature Switch	CMM
Pneudraulics	9668	Thermal Bypass Valve	CMM
Pneudraulics	9686		CMM